

# Intellex Software Update version 2.3.4

**Installation Instructions**      **NOTE:** This update only applies to Intellex software version 2.3.4. To determine the version of software on your Intellex, click on **Utility**, then on **About Intellex**. The version will be displayed in the information dialog.

**Introduction**      This software update corrects two problems that can occur in Intellex software version 2.3.4.

- The Alarm list problem occurs when large numbers of alarms (over 32,000) are registered in the database and they are no longer displayed in the alarm list. They are still available through a database search.
- The 11,000 day problem can occur when extended storage is added to the database or when a power failure causes database corruption. The symptom is that the Time Span displayed in the **Status** screen is over 11,000 days.

This update also expands the CD-RW drive compatibility to include the 24X and 40X write speed drives with the part numbers 2025-0339-05 and 2025-0339-07.

**Download and Installation Instructions**      Click on the link **Intellex 2.3 Update** below and save the file to your hard disk or a floppy disk.

- Copy the file to the appropriate media (a CD-R or floppy disk) that is compatible with the removable media drive in the Intellex.
- On the Intellex, insert the media with the update into the unit's drive. Exit the Intellex application and double-click on the **My Computer** icon. Double-click on the drive icon and then on the executable file on the media. Read and respond to any messages displayed by the installer.
- When the installation is complete, the Intellex will reboot. Be sure to remove the update media before the unit reboots.

Intellex will automatically start and resume recording. There will not be a message displayed in the **About Intellex** box, but the update will be working.