

# UPDATING INTELLEX 3.X DRIVERS FOR VACD BOARD 0301-1101-03

---

These instructions describe the procedure for updating the driver software for the VACD board 0301-1101-03 for Intellex. The VACD board 0301-1101-03 replaces 0301-1101-01 or 0301-1101-02. The Intellex unit must be running software version 3.0 or 3.1.

## REQUIREMENTS

- Intellex system with software version 3.0 or 3.1
- Driver update 0720-0341-0100
- VACD board 0301-1101-03

## INSTALLATION INSTRUCTIONS

**CAUTION:** Protect against ESD! The VACD board and other circuitry inside the Intellex is sensitive to damage from ESD. Observe proper ESD prevention practices whenever circuit boards within the Intellex are handled.

1. Unplug the Intellex power cable and remove the cover.
2. Replace the old VACD board with the new VACD board (P/N 0301-1101-03).
3. Replace the cover and plug in the power cable.
4. A dialog box appears indicating that Intellex has generated errors. Close the dialog box.

**NOTE:** If there are no error messages and Intellex starts normally, then the driver update has already been installed.

5. A "Found New Hardware Wizard" dialog box appears.
6. Click **Cancel**.
7. Insert the disk with the VACDPNXUpdate into the floppy drive.
8. Run the VACDPNXUpdate application.
9. Remove the floppy disk.
10. Click **Finish** and let Intellex restart.
11. Another dialog box appears indicating that Intellex has generated errors. Close the dialog box.
12. Another "Found New Hardware Wizard" dialog box appears.
13. Click **Next** in the dialog box, then click **Next** in the two subsequent dialog boxes that appear.

14. Another dialog box appears indicating the driver path. Do one of the following:
  - If the path is set for C:\WINNT\system32\drivers, then click **OK**.
  - If that is not the path, then click **Browse** to set the path to C:\WINNT\system32\drivers.
15. The next dialog box should say, "Windows found a driver for this device." Click **Next**, then **Finish**.
16. From the **Start** menu, select **Shut Down** and then select **Restart** to reboot the system.
17. Intellex will start after the reboot.

Thank you for using American Dynamics products. We support our products through an extensive worldwide network of dealers. The dealer through whom you originally purchased this product is your point of contact if you need service or support. Our dealers are empowered to provide the very best in customer service and support. Dealers should contact American Dynamics at (800) 507-6268 or (561) 912-6259 or on the Web at [www.americandynamics.net](http://www.americandynamics.net).

© Copyright 2003 Sensormatic Electronics Corporation  
Intellex® is a trademark of Sensormatic Electronics Corporation.

**American Dynamics**  
6795 Flanders Drive  
San Diego, California 92121-2903